

SUN TOUR TRIGGER LEVER

Assy No.	CODE NO.	PART NO.	NOMENCLATURE	REFERENCE COLUMN
1	3277 00		Trigger unit	
2	3000 5557 00		Clip screw	
3	2000 5571 00		Clip nut	
4	3197 1901 00		Outer cable stopper	
5	3002 0353 05		Outer cable	
6	3197 3901		Outer cable sleeve	
7	3197 2081 00		Fulcrum clip	1"
7	3197 2901 00		Fulcrum clip	1-1/8"
8	5521 81		Pulley clip	1"
8	5521 91		Pulley clip	
9	5521 3101 00		Pulley wheel	
10	5521 0201 00		Pulley arm	
11	3000 5421 00		Pulley arm screw	
12	3197 2201 00		Anchor screw	
13	3197 2101 00		Joint bracket	
14	3000 8012 00		Anchor washer	
15	3197 2301 00		Indicator coupling adjuster nut	
16	3197 2401 00		Indicator coupling lock nut	
17	4011 09		Toggle chain	
18	3275 01		Complete cable	
19	3197 2601		Outer casing holder	
20	3270 01		Complete cable	
21	5531 0153 00		Outer casing clip	1/2"
22	5531 0145 00		Outer casing clip	9/16"
23	5531 0155 00		Outer casing clip	11/16"